

## CAC-1085 QUICK INSTALLATION GUIDE

DisplayPort™1.4 to HDMI™ 4K120Hz HDR Active adapter M/F



**Thank you for purchasing our CAC-1085 Product.** After unpacking the product, please make sure you have all the items provided and checked for any damages. In case of any missing/damaged parts please inform your supplier immediately.

## You should have:

- CAC-1085 DisplayPort<sup>™</sup>1.4 to HDMI<sup>™</sup> 4K120Hz HDR Active adapter M/F
- USB Type A to USB Type C for external power

Please update: your Graphic drivers to support the these resolutions/refresh rates. Please update: your TV Firmware to the version which supports these resolutions/refresh rates ! - HDMI<sup>™</sup>-out Please make sure: the HDMI<sup>™</sup> cable is capable of handling 48Gbps to support 4K12OHz. The maximum length allowed here is 2m or 6.56 ft. CAC-1085 USB Type A to USB Type C cable for external power. The USB Type C port for connecting the external power cable. To DisplayPort™ HDMI<sup>™</sup> port: Connect the CAC-1085 adapter with your HDMI<sup>™</sup> cable to the device you want to connect. Connect the CAC-1085 adapter with the supplied USB cable to an USB power source. The USB power from your computer is sufficient.



Disclaimer:

While we endeavor to provide the most accurate, up-to-date information available, the content of this document may be out of date or include omissions, inaccuracies or other errors. Therefore Club 3D does not accept any rights claimed on the content of this document. Please refer to a full overview of our Legacy Terms and Conditions on www.club-3d.com. All other brand names are trademarks or registered trademarks and are the property of their respective owners. All content is subject to change without prior notice.